quick reference guide – MANO EDU XL

EN



1) DC port
2) ON/OFF
3) HDMI input
4) HDMI output
5) SD card slot
6) camera switch
7) line/mask button
8) home
9) color mode
10) joystick
11) zoom
12) TTS function
13) microphone
14) headphone / loudspeaker socket
15) volume +/-
16) autofocus
17) freeze frame

A Hold the base plate with one hand and unfold the stand

B Adjust the display to a comfortable viewing position and optionally raise it at the side and adjust it vertically

C Unfold the distance camera and turn it in the desired direction

A



B



C



quick reference guide – MANO EDU XL

Operation in magnification mode and menus		
	short press: battery status	long press: switch ON/switch OFF/standby
	short press: show/hide menu bar	long press: open menu
	turn controller: change color mode	press controller: switch between true colors and artificial colors
	horizontal and vertical navigation in magnification mode; navigation within the picture gallery; adjust size and position of ruler and line masking	
	turn controller: zoom in/out	press controller: overview mode
	zoom in/out: use the pinch and zoom gesture	
	tap on the magnified image with your fingers and move it	
	short press: switch the camera image long press: enter A4 reading mode	
	short press: switch between line marker and mask	
	short press: freeze image	long press: save image
	short press: start reading (current image section) short press in menus and galleries: confirm selection	long press: start reading (A4 page) long press in galleries: multiple selection
	in menus and galleries: tap with your finger on an icon to select it	

Operation in TTS mode			
	short press: show/hide menu bar long press: exit TTS mode		turn controller: zoom in/out press controller: original zoom
	switch between image- and text mode		text segmentation ON/OFF
	start/stop reading		back/forward by segment/by sentence
	adjust reading speed		in image mode: save image in text mode: save text