quick reference guide – MANO EDU



1) power port
2) ON/OFF
3) HDMI input
4) HDMI output
5) USB-C port
6) SD card slot
7) camera switch
8) line marker/mask
9) microphone
10) distance camera
11) headphones/ loudspeaker jack
12) volume control
13) autofocus
14) freeze button







A Hold the base plate with one hand and unfold the stand

B Bring the display into a comfortable viewing position

C Unfold the distance camera and turn it in the desired direction

quick reference guide – MANO EDU

Operation in magnification mode and menus		
	short press: battery status	long press: switch ON/switch OFF/standby
	short press: show/hide menu bar	long press: open menu
	turn controller: change color mode	press controller: switch between true colors and artificial colors
	horizontal and vertical navigation in magnification mode; navigation within the picture gallery; adjust size and position of ruler and line masking	
	turn controller: zoom in/out	press controller: overview mode
	zoom in/out: use the pinch and zoom gesture	
	tap on the magnified image with your fingers and move it	
	short press: switch the camera image long press: enter A4 reading mode	
	short press: switch between line marker and mask	
	short press: freeze image	long press: save image
	short press: start reading (current image section) short press in menus and galleries: confirm selection	long press: start reading (A4 page) long press in galleries: multiple selection
	in menus and galleries: tap with your finger on an icon to select it	

Operation in TTS mode			
	short press: show/hide menu bar long press: exit TTS mode		turn controller: zoom in/out press controller: original zoom
	switch between image- and text mode		text segmentation ON/OFF
	start/stop reading		back/forward by segment/by sentence
	adjust reading speed		in image mode: save image in text mode: save text