quick reference guide – MANO EDU lite

EN



1) ON/OFF
2) DC port
3) HDMI output
4) headphone / loudspeaker socket
5) camera switch
6) line/mask button
7) SD card slot
8) front camera
9) home
10) color mode
11) joystick
12) zoom
13) enter
14) volume +/-
15) distance camera connection
16) autofocus
17) freeze frame

Fold out the stand and place the device on the reading material



Insert the camera arm into the connection on the right-hand side of the device



quick reference guide – MANO EDU lite

distance camera:
- turn gray marking to the front
- camera arm points straight up



document camera:
- turn the gray marking to the side until the marking next to the hinge is visible
- bend the camera arm carefully to the side



Operation in magnification mode and menus			
	short press: battery status	long press: switch ON/switch OFF/standby	
	short press: show/hide menu bar	long press: open menu	
	turn controller: change color mode	press controller: switch between true colors and artificial colors	
	horizontal and vertical navigation in magnification mode; navigation within the picture gallery; adjust size and position of ruler and line masking		
	short press: confirm selection	long press: multiple selection	
	in menus and galleries: tap with your finger on an icon to select it		
	turn controller: zoom in/out	press controller: overview mode	
	zoom in/out: use the pinch and zoom gesture		
	tap on the magnified image with your fingers and move it		
	short press: switch between internal/external camera		in the menu bar: switch between rear camera/front camera
	short press: switch between line marker and mask		
	short press: freeze image		long press: save image